


Instructions & Warranty Information



COMBINATION LOCK INSTRUCTIONS

- // 1. With the lock open, push button (1) in the direction of the arrow show above and hold down until the second operation has been performed.
- // 2. Set number wheels (2) to the desired combination. Do not forget the combination you have set.
- // 3. Now release button (1). Press the button again as a check to ensure it opens.
- // 4. To lock, spin all three combination number wheels (2) to random positions

WARRANTY INFORMATION

- // All Pro-Tactical alloy gun case come with a 2 year warranty, for mechanical faults. Damage claims will be warranted at the discretion of Pro-Tactical.

